



“His Master’s Voice”

SERVICE MANUAL

for

FOUR VALVE

BROADCAST BATTERY OPERATED MODEL 51

BROADCAST VIBRATOR OPERATED MODEL 61

DUAL-WAVE BATTERY OPERATED MODEL 52

DUAL-WAVE VIBRATOR OPERATED MODEL 62

TECHNICAL SPECIFICATION

BATTERIES

Model	"A" Supply	"B" Supply
51	Air-Cell or 2-volt 110 amp. hr. Accumulator	2 x 45-volt Heavy Duty Batteries
52	do.	2 x 45-volt Superdyne Batteries
61	2-volt 190 amp. hr. Accumulator	Vibrator
62	do.	do.

The accumulator, where supplied with the receiver, is already fully charged.

This battery should be recharged at least every two months, or alternatively whenever the specific gravity as measured with a hydrometer falls below 1.140, or the voltage, with the receiver in operation, falls below 1.8 volts.

CONSUMPTION

Model	"A" Supply	"B" Supply
51 and 52	.. 0.34 amp.	12 ma.
61 and 62	.. 1.7 amp.	

SPEECH OUTPUT

270 milliwatts undistorted (plate circuit).

WAVE-LENGTH RANGE

Models 51 & 61: 200-545 metres (1500-550 kc.).
 .. 52 & 62: 200-545 metres (1500-550 kc.).
 16.5-49 metres (18.17-6.12 mc.)

DIMENSIONS

Height 15"	Width 11"	Depth 8"
------------	-----------	----------

WEIGHT

	Net	Gross
Model 51	17 lbs.	21 lbs.
.. with Batteries	51 lbs.	62 lbs.
Model 52	18 lbs.	22 lbs.
.. with Batteries	59 lbs.	70 lbs.
Model 61	25 lbs.	29 lbs.
.. with Battery ..	50 lbs.	58 lbs.
Model 62	26 lbs.	30 lbs.
.. with Battery ..	51 lbs.	59 lbs.

VALVES

1C7G Converter.
 1D5G I.F.
 1F7G Demodulator, A.V.C. and 1st A.F.
 1Q5G Power.

LOUDSPEAKER

The speaker used is of the permanent magnet dynamic type. It is a 6-inch model with a voice coil impedance at 400 cycles of 3.5 ohms.

CIRCUIT DESCRIPTION

These models employ a 4-valve superheterodyne chassis comprising a Pantagrid converter followed by an I.F. amplifier. Demodulation is effected and A.V.C. voltage is obtained in the diode circuits of the following valve, which is a duo-diode-pentode; the pentode section of this valve functions as an

audio amplifier and is resistance-capacity coupled to the output valve, which is of the beam tetrode type.

Coupling to the aerial on the broadcast band is effected through an iron-cored transformer having the normal tuned secondary.

The I.F. transformers are permeability tuned and employ Litz-wound coils with sliding iron cores.

Full A.V.C. voltage is applied to the converter and I.F. valves whilst partial A.V.C. is taken to the audio valve; no A.V.C. voltage is applied to the S.W. converter grid.

Padding on the broadcast band is effected by adjustment of the oscillator secondary inductance, by means of an adjustable iron core, in conjunction with a fixed padding condenser. On the short-wave band no padding adjustment is required.

All R.F. trimmers are of the air dielectric type, using a robust plunger type construction, which is entirely immune to change of capacity or detrimental atmospheric influences.

When the chassis is operated with a vibrator unit, the bias on the power valve grid is obtained from the voltage drop across the smoothing choke in the H.T. negative lead.

When operated with battery H.T., this bias is derived from a voltage drop across a resistor in the H.T. negative lead.

This change of circuit connections is automatically accomplished by plugging the appropriate cable into the proper battery socket on the chassis.

By this means it is possible to convert Models 51 and 52 into Models 61 and 62 respectively by merely plugging in a vibrator unit cable in place of the battery cable.

A suitable resistor of 0.83 ohms. is provided in the receiver to reduce the voltage of the Air-Cell to the correct value, and this resistor is automatically brought into circuit by the use of the correct Air-Cell battery connection cable; when the accumulator type battery cable is in use, this resistor is removed from circuit.

CAUTION

It is not advisable to alter the length of any of the battery connection cables, because their resistance forms part of the total series resistance introduced to obtain correct filament voltages.

WAVE BAND SWITCHING (Models 52 and 62)

This is carried out by means of a two-position switch. The oscillator primary coils are connected in a series and are not switched; however, a little feed-back is applied across the padding condenser on the S.W. band, and this is switched in and out by contacts on the wave-change switch.

In the first position of the switch (anti-clockwise) the receiver is adjusted for short-wave reception and in the second position for broadcast reception

TONE MONITOR (Combined with Battery Switch)

The tone is controlled by a four-position two-deck switch, the first position on which switches the receiver off; the second position switches the receiver on and gives normal reproduction, while the third and fourth positions introduce an increasing degree of high-frequency cut by means of a condenser resistor combination shunted across the speaker transformer primary.

DIAL LAMP (2.5v. 0.3amp.)

The dial lighting is controlled by a push-button mounted on the side of the cabinet, which should be pressed during the process of tuning-in a station. When released, this button will extinguish the dial lighting, thus saving unnecessary drain on the battery.

VIBRATOR CIRCUIT DESCRIPTION (Models 61 and 62)

The circuit of the vibrator unit is indicated on page 6. This unit includes the vibrator cartridge, which is enclosed in a separate metal container arranged so that it can be plugged into or removed from a socket located in the vibrator unit in a manner similar to a valve. The vibrator socket is arranged with a sponge rubber mounting so as to ensure a minimum of mechanical noise being transmitted to the cabinet.

The remainder of the unit consists of the necessary transformers and filters.

Important Note.—It is essential that the resistance of the 5-amp. fuse in the vibrator positive L.T. circuit should not exceed 0.01 of an ohm, otherwise the performance and battery life will suffer. Use only Australux 5-amp. fuse, type 1AG.

PRELIMINARY TESTS

1. Check over battery connections in accordance with the diagram on page 6.
2. Check over battery voltages as specified in paragraph headed "Batteries."
3. Remove fuse from A— vibrator lead and check for continuity in the fuse (Models 61 and 62).
4. Switch the receiver on by means of the combined battery and Tone Monitor switch, and, having removed the earth wire and turned the volume control to the maximum position, touch the finger to the grid of the 1F7G valve (1st AF). A loud hum should be heard; this denotes that the audio frequency side of the receiver is functioning and the fault probably lies in the valves or associate circuits ahead of this position. Should no hum be heard, the fault will have developed between the first audio and output stage.
5. Check all valves for filament continuity and freedom from internal shorts.
6. To determine if the fault lies in the loudspeaker, connect a high-impedance A.C. voltmeter or output meter, with a range of approximately 0.3 volts, across the voice coil terminals on the speaker. With the receiver switched on and adjusted for the broadcast band, turn the volume control fully on and rotate the tuning control. If no deflection is given by the meter the fault lies in the receiver chassis. If a deflection is obtained, but no audible sound, the loudspeaker is at fault.
7. If the fault is still undiscovered, remove the chassis from the cabinet and compare voltages with the voltage table given on page 7.

DISMANTLING

REMOVAL OF CHASSIS

1. Turn tuning control so that gang condenser plates are fully meshed.
2. Remove knobs.
3. Disconnect loudspeaker and battery plug.
4. Remove rear cabinet support bar.
5. Loosen nut on pilot lamp switch and remove.
6. Remove four fixing screws from underside of cabinet; the chassis is now free.

REMOVAL OF VIBRATOR UNIT (Models 61 and 62)



(**Note.**—Replacement of the vibrator cartridge may be effected at any time without removal of the entire unit from the cabinet. This may be accomplished by removing the nine screws which hold the

vibrator unit cover in place; on lifting this cover plate all vibrator components will be accessible.)

1. Remove rear cabinet support bar.
2. Disconnect cable plug from chassis.
3. Remove the two screws at the top rear of cabinet.
4. Remove the two screws holding unit to speaker support bar; the unit is now free and may be withdrawn from the cabinet.

REMOVAL OF LOUDSPEAKER

1. Remove vibrator unit (Models 61 and 62 only).
2. Disconnect speaker leads from jacks.
3. Remove screws at each end of speaker support bar.
4. Remove four nuts holding speaker chassis and remove speaker.



Editorial Office for Asia, Africa, Europe, & Latin America

VOLTAGE TABLE

The receiver should be tuned to a point of no reception on the BC band. Values given are $\pm 10\%$ with the exception of filament voltages which are $\pm 5\%$. All voltage readings above 10 volts are taken on the 250-volt scale of a 1000 ohms per volt voltmeter. If a voltmeter with an internal resistance of less than 1000 ohms per volt is utilised, allowance must be made for the voltage drop caused by the voltmeter. Note that, with vibrator H.T. supply, it will not be possible to measure the power valve grid bias at the chassis due to the presence of a 0.25 megohm decoupling resistor in the vibrator unit; however, this voltage may be measured at the vibrator unit.

MODEL 51 AND 52 (BATTERY H.T.).

	1C7G	1D5G	1F7G	1Q5G
Plate to chassis volts	84	84	15	82
Plate current (ma)	1.2	1.4	0.3	4.5
Osc. plate to chassis volts	BC 60	SW 69	—	—
Osc. plate current (ma)	1.7	1.7	—	—
Screen to chassis volts	37	37	19	84
Screen current (ma)	1.0	0.6	0.1	0.7
Bias voltages	0	0	0	-6.3
Filament voltages— With air cell=2.33 volts Or Accumulator=2.0 volts	1.85	1.85	1.85	1.37

MODELS 61 AND 62 (VIBRATOR H.T.).

	1C7G	1D5G	1F7G	1Q5G
Plate to chassis volts	86	86	15	84
Plate current (ma)	1.3	1.6	0.3	5.9
Osc. plate to chassis volts	BC 61	SW 70	—	—
Osc. plate current (ma)	1.7	1.7	—	—
Screen to chassis volts	40	40	19	86
Screen current (ma)	1.0	0.7	0.1	0.9
Bias voltages	0	0	0	-5.8
Filament voltages Accumulator=2.0 volts.	1.85	1.85	1.85	1.37

RADIO FREQUENCY TESTS AND ADJUSTMENTS

Instability, insensitivity or poor selectivity may indicate that the alignment of the tuned circuits is not correct. If a coil or other component associated with the R.F. or I.F. side of the receiver has been replaced or repaired, or if the wiring has been disarranged, all circuits must be realigned.

To do this, the following apparatus is required:

1. An oscillator or signal generator capable of tuning to 1500 kc., 1400 kc., 600 kc., 460 kc., 16.5 metres and 17 metres, suitably screened and with an attenuator.
2. An output meter having a range of 0.2 volts A.C. approximately.

I.F. alignment should always precede R.F. alignment, and even if only one coil or one range of coils has been serviced, the whole of the realignment

should be done in the order given, i.e., broadcast band first followed by short-wave band.

In carrying out the following operations, it is important that the input to the receiver from the oscillator should be kept low and progressively reduced as the circuits are brought into line, so that the reading on the output meter does not exceed about 0.5 volt.

For all alignment operations, the output meter should be connected across the loudspeaker voice coil.

I.F. ALIGNMENT

The sketches on page 8 show the layout of all principal components and adjustments referred to in the procedure following.

