

DŔUM

Model 9X-900S Schematic Diagram



Model 9X-900S Bottom View of Printed Circuit Board



ALIGNMENT PROCEDURE CHART

Step	ConnectSignal Generatorto	Band Selector to	Generator Frequency	Dial (VC) Setting	Adjust for Maximum		
1	Terminal of VC ₁ through 1~3 pF Capacitor	MW	455 kc	Maximum Freq.	T ₁₂ , T ₁₁ , & T ₁₀ in order		
2			600 kc	600 kc	MW osc. coil T ₇		
3			"	"	MW RF coil T4		
4			"	"	MW ant. coil T ₁		
5			1400 kc	1400 kc	MW osc. trimmer Tr7		
6			. "	"	MW RF trimmer Tr4		
7			"	"	MW ant. trimmer Tr ₁		
8		Repeat Steps 2~7					
9		SWr	4 Mc	4 Mc	SW ₁ osc. coil T ₈		
10			"	"	SW ₁ RF coil T ₅		
11			"	"	SW ₁ ant. coil T ₂		
12			8 Mc	8 Mc	SW ₁ osc. trimmer Tr ₈		
13			8.9 Mc	"	Increase generator output until image signal is heard. If not heard, return to step 12 and Tr ₈ must be rotated until another signal is heard.		
14			8 Mc	"	SW ₁ RF trimmer Tr ₅		

MITSUBISHI Model 9X-900S

15			8 Mc	8 Mc	SW ₁ ant. trimmer Tr ₂			
16	Repeat Steps 8~15, until no further change is noted							
17			10 Mc	10 Mc	SW2 osc. coil T9			
18		-	"	"	SW ₂ RF coil T ₆			
19			"	"	SW2 ant. coil T8			
20			18 Mc	18 Mc	SW2 osc. frimmer Tr9			
21	Ditto	SW ₂	18.9 Mc	"	Increase generator output until image signal is heard. If not heard, return to step 20 ang Tr ₀ must be rotated until another signal is heard.			
22			18 Mc	"	SW ₂ RF trimmer Tr ₆			
23		٠.	"	"	SW2 ant. trimmer Tr3			
24	Repeat Steps 17~23 until no further change is noted.							

Model 9X-900S Bottom View of Printed Circuit Board

