

SHARP MODEL ATR-910

SPECIFICATIONS

Circuit: 7-transistor, 1-band superheterodyne system with AGC.

530-1605KC Frequency Range: Intermediate Frequency: 455KC

Power Output: 1.5/0.6W at 13.2/6.5V


Power Supply: 6/12V DC car battery positive and negative grounding

Power Consumption: 4W/2W at 13.2/6.5V

Speaker: 4" permanent dynamic speaker Dimensions: $6\frac{1}{4}$ " (W) $\times 2$ " (H) $\times 6\frac{1}{4}$ " (D)

Weight: 2.6 lbs (1.2kg)

LOCATION OF PARTS




Should it become necessary at any time to check the alignment of this receiver, proceed as follows;


- 1) Connect an output meter across the speaker voice coil lugs.
- 2) Set volume control to maximum.
- 3) Use the lowest setting of signal generator capable of producing adequate indication on the lowest scale of output meter.
- 4) Use a non-metallic alignment tool.
- 5) Repeat adjustments to insure good results.

ALIGNMENT CHART

Signal generator				Receiver		Adjust
Step	Band	Connection to receiver	Input signal frequency	Dial setting	Remarks	Adjust
1	M.W.	Connect signal generator through the appointed dummy to the external antenna.	Exactly 455KC. (400%, 30%, AM modulated.)	The highest frequency range	Adjust for maximum output on speaker voice coil lugs.	4th-IF Trans. core 3rd-IF Trans. core 2nd-IF Trans. core 1st-IF Trans. core
2	M.W.	Same as step 1.	Exactly 520KC. (400%, 30%, AM modulated.)	The lowest frequency range	Same as step 1.	MW Oscillator core (red)
3	M.W.	Same as step 1.	Exactly 1650KC. (400%, 30%, AM modulated.)	Same as step 1.	Same as step 1.	MW Oscillator trimmer (C ₃)
4	M.W.	Same as step 1.	Exactly 1400KC. (400%, 30%, AM modulated.)	1400KC	Same as step 1.	MW Antenna trimmer (C ₁) RF trimmer (C ₂)
5	M.W.	Repeat steps 2, 3 and 4 until no further improvement is obtained.				

APPOINTED DUMMY ANTENNA





Emitt

TRANSISTOR VOLTAGE (VOLTS)

Coll-

TR NO

TRANSISTOR

SHARP ATR-910

