



NOTES—Arrow on potentiometer indicates direction of clockwise rotation.  
 Voltages measured with 20,000 ohm/volt meter under no signal condition.  
 Voltages shown are positive with respect to the chassis i.e. battery negative terminal.



