SCHEMATIC DIAGRAM



TROUBLE SHOOTING

	TROUBLE	PROBABLE CAUSE	REMEDY
1.	Fails to play (Dial light off)	No Power	Check connection to fuse block.
		Fuse Blown	Replace fuse.
		No Ground	Check ground to ANT cable.
2.	Fails to play (Dial light on)	Defective ANT Cable	Check all cables and connections.

3. Be sure proper considerations are made with the Power Supply.