CARE OF CABINET

A P.V.C. plastic material has been used for covering the cabinet.

It is suggested that only warm soapy water should be used for cleaning the cabinet.

PARTS LIST

PART NO.	ITEM
TU9B	4 Speed record player
RS507–42	Driver transformer
RS407–43	Speaker transformer
RS517–98	Rola 5F speaker
CZ9A	Thermistor
691/5/2	Battery plug
SP40966A	Ferrite Rod Aerial Assy.
SP40943A	Tuning condenser
SP40894C	Volume control potentiometer
SP40783K	Tone control potentiometer
SP40995A	Selector switch
SP40959	Extension spindle
SP40988DV	Cabinet (blue/grey or tan/fawn)
SP40958AE	Dial cards
SP54109C	Monogram
SP40952B	Medallion
SP40295	Grille (tan or blue)
SP30661	Rubber foot
SP40933C	I.F. transformer
SP40934A	I.F. transformer
SP40926	Dial knob assy.
SP40954	Control knob assy.
SP40935A	Oscillator coil assy.