SERVICING:

To remove the record player proceed as follows:–

Remove the base and batteries. Unscrew the 6 volt battery contact from the rear of the cabinet and remove the connections to the receiver chassis. Remove the circlip from the lower end of the turntable spindle, then from the top of the cabinet, lift off the turntable. Remove the nuts from the three exposed holding down screws and remove the complete motor assembly from the cabinet.

To remove the receiver proceed as follows:–

Remove the base and batteries. Unplug all connections from the receiver chassis. Withdraw the tone control, volume control and selector switch knobs. Rotate the dial knob until the grub screw on the extension spindle is accessible. Loosen the grub screw and withdraw the dial knob. Withdraw the dial scale and remove the exposed screws. Remove the two chassis holding screws at the switch end of the chassis and withdraw the chassis.

Any alignment, adjustments or replacement of components may then be carried out.

To re-assemble, the above instructions should be carried out in reverse.

IMPORTANT NOTES:

For a number of important points to be observed when servicing transistorised equipment, refer to the section under this heading in Service Bulletin No. 133.