9. HOW TO REPLACE THE VOLUME CONTROLLER



Fig. 9-1

1) Take off the upper cover case of the chassis. Take off the screws fixing the cover case to the chassis and open the cover case inserting a screw driver into the indented part of the back side of the set. (See Fig. 9-1)



Fig. 9-2

2) Take off the knobs and the tuning shaft and nut of the volume controller which fix the escutcheon board.
Unscrew 2 screws in the lower part of the escutcheon, then the board can be taken off. (See Fig. 9-2)



Fig. 9-3

3) Take off the lead wires connected to terminals of the volume controller and replace it with new one. (See Fig. 9-3)



Fig. 9-4

4) Pass the spacer to the volume shaft.
Be careful of the direction of the spacer.
Attach the escutcheon board again and fasten the screws. (See Fig. 9-4)