3.	To antenna terminal	1.7 Mc/s.	400 ohm non-inductive resistor	Turn cond. gang and dial pointer until centre of dial pointer is on 1.7 Mc/s mark on dial. Leave the cond.gang and dial pointer set in this position. Repeak 1.6-4.5 Mc/s. band oscl. coil ind. trim. (iron core) then peak the 1.6-4.5 Mc/s. band antenna and RF trans.ind. trim. (iron cores) for max. output. Do not rock the condenser gang to and fro through the signal or move the dial pointer off the 1.7 Mc/s. dial mark until after the ind. trim (iron core) of the three coils has been peaked for max. output.
4.	To antenna terminal	4.2 Mc/s.	400 ohm non-inductive resistor	Turn cond. gang and dial pointer until centre of dial pointer is on 4.2 Mc/s. mark on dial. Readjust 1.6-4.5 Mc/s. band oscl. coil trim cond. for logging then repeak 1.6-4.5 Mc/s band antenna and RF trans. trim. condensers for max. output. Rock cond. gang to and fro through the signal while adjusting the antenna and RF. trans. trim. conds.
5.	To antenna terminal	3 Mc/s.	400 ohm non-inductive resistor	Check tracking at 3 Mc/s.

SHORT-WAVE BAND ALIGNMENT 4.4-9.2 Mc/s.

1.	To antenna terminal	4.5 Mc/s.	400 ohm non-inductive resistor	Turn wave change switch to 4.4-9.2 Mc/s band position. Turn cond. gang and dial pointer until centre of dial pointer is on 4.5 Mc/s. mark on dial. Leave cond. gang and dial pointer set in this position and peak the 4.4-9.2 Mc/s. band oscl. coil ind. trim. (iron core) and the 4.4-9.2 Mc/s. band antenna and RF trans. ind. trim (iron cores) for max. output.