				Leave the cond. gang and dial pointer set in this position, and peak the 9.1-14.5 Mc/s. band oscl. coil ind. trim. (iron core) and the 9.1-14.5 Mc/s. band antenna and RF trans. ind. trim. (iron cores) for max. output.
2.	To antenna terminal	14.2 Mc/s.	400 ohm non-inductive resistor	Turn cond. gang and dial pointer until centre of dial pointer is on 14.2 Mc/s. dial mark. Adjust 9.1-14.5 Mc/s. band oscl. coil trim. cond. for logging, then peak 9.1-14.5 Mc/s. band ant. and RF trans. trim. conds. for max. output.
3.	To antenna terminal	9.6 Mc/s.	400 ohm non-inductive resistor.	Turn cond. gang and dial pointer until centre of dial pointer is on 9.6 Mc/s. dial mark. Leave the cond. gang and dial pointer set in this position and repeak the 9.1-14.5 Mc/s. band oscl. coil ind. trim. (iron core) and the 9.1-14.5 Mc/s. band ant. and RF trans. ind trimmers (iron cores) for max. output. Do not rock the cond. gang to and fro through the signal or move the dial pointer off the 9.6 Mc/s. dial mark until after the ind. trim, (iron core) of the three coils has been peaked for max. output.
4.	To antenna terminal	14.2 Mc/s.	400 ohm non-inductive resistor	Turn cond. gang and dial pointer until centre of dial pointer is on 14.2 Mc/s. mark on dial. Readjust 9.1-14.5 Mc/s. band oscl. coil trim. cond. for logging, then repeak 9.1-14.5 Mc/s. band antenna and RF trans. trim. conds. for max. output. Rock the cond. gang to and fro through the signal while adjusting the antenna and RF trans. trim, conds.
5.	To antenna terminal	11.8 Mc/s.	400 ohm non-inductive resistor	Check tracking at 11.8 Mc/s.