

Operating Instructions

ON-OFF & VOLUME

The ON-OFF switch and VOLUME control are combined and are operated with the left hand knob.

MANUAL TUNING

Radio stations are manually tuned by rotating the right hand knob in either direction until the desired station is received. Tune carefully until radio is exactly tuned to the station; tuning to either side of the station will result in poor tonal quality and noisy reception.

TONE CONTROL : Permits selection of tonal range of sound.

PUSHBUTTON TUNING

Pressing any one of the buttons will automatically tune the radio to the station for which the pushbutton has been set.

SETTING PUSHBUTTONS

1. Carefully tune-in the desired station with the MANUAL TUNING control. Tune exactly to the station.
2. Pull out the first pushbutton to be set, to unlock the button for station set-up, and then lock this button to the station which you have tuned-in by firmly pushing the button in.
3. Follow the above procedure for the remaining four buttons.

CAUTION

1. ADJUST ANTENNA TRIMMER

a) Extend antenna fully; turn radio on and tune in a weak station around 1400 KHz.

b) Adjust the antenna trimmer for maximum output on the speaker.