PARTS LIST

N.B. Part No. is also used for Identification on exploded view of deck.

PART No:	DESCRIPTION
1.	Metal Chassis
2.	Friction Lock Screw M2.6 x 4
3.	Friction Lock Screw M2.6 x 4
4.	Push Button Assy.
5.	Rollers - Head Panel
6.	Head Panel
7.	Vinyl Tube
8.	Spring - Head Panel
9.	Stud - Erase Head
10.	Erase Head
11.	Screw - Head MTG
12.	Stud - Record/Play Head
13.	Spring - Record/Play Head
14.	Record/Play Head
15.	Azimuth Adjusting Screw
16.	Screw - Head MTG M2 x 3
17.	Spring - Pinch Roller
18.	Screw - M3 x 4 ISO
19.	Spring Washer
20.	Pause Bracket
21.	Pinch Roller Assy.
22.	E Ring 1.9
23.	Friction Lock Screw M2.6 x 4
24.	Friction Lock Screw M2.6 x 4
25.	Spring Hanger A
26.	Screw M2.6 x 3
27.	Retainer - Head Panel
28.	Steel Ball
29.	Spring Hanger B
30.	E Ring 2.3
31.	Shaft - Cassette Holder
32.	Spring - Cassette Holder
33.	Cassette Holder Assy.
34.	Friction Lock Screw M2.6 x 4
35.	Friction Lock Screw M2.6 x 4
36.	Cassette Holder Support A
37.	Cassette Holder Support B
38.	Take Up Reel Cap
39.	Take Up Reel Assy.
40.	Supply Reel Cap
41.	Supply Reel Assy.
42.	Shaft - Brake
43.	Spring - Brake
44.	Brake
45.	Screw M2.6 x 5
46.	Spacer
47.	Record Interlock Lever
48.	Screw M2.6 x 5
49.	Cassette Release Timing Bracket
50.	Friction Lock Screw M3 x 10 ISO
51.	Friction Lock Screw M3 x 10 ISO
52.	Clamp - Motor
53.	Screw M3 x 10 ISO
54.	Rubber Cushion
55.	Belt - Counter
56.	Counter
57.	Screw M2.6 x 4
58.	Spring Washer
59.	Holder - Counter
60.	Screw M3 x 5 ISO
61.	Spring - Rewind Action Plate
62.	E Ring 2.3
63.	Rewind Action Plate
64.	Shaft - Rewind Action Plate
65.	Screw - M2.6 x 4
66.	Spring Washer
68.	Fast Forward Idler Arm Guide
69.	Screw M2.6 x 3
70.	Washer
71.	Fast Forward Idler Arm Spring Plate
72.	E Ring 1.5
73.	Nylon Washer
74.	Fast Forward Idler Arm Assy.

PART No:	DESCRIPTION
75.	Spring - Brake Release Plate
76.	Spring - Fast Forward Arm
77.	Vinyl Tube
78.	E Ring 1.5
79.	Vinyl Washer
80.	Brake Release Plate
81.	Spring - Rewind Idler Arm
82.	Rewind Idler Arm Assy.
83.	Screw M2.6 x 5
84.	Spacer
85.	Connecting Rod
86.	Record Interlock Latch
87.	Spring - Record Interlock Latch
88.	Vinyl Tube
89.	Pause Cam Assy.
90.	E Ring 3.2
91.	Brass Washer
92.	Spring - Pause Arm
93.	Pause Arm
94.	E Ring 1.5
95.	Washer
96.	Pause Lever
97.	E Ring 3.2
98.	Brass Washer
99.	Pop-Up Hook Plate
100.	Spring for Pop-Up Hook Plate
101.	Nut
102.	Spring Washer
103.	Rewind Arm Retainer
104.	Spacer
105.	Hexagonal Special Nut
106.	Spacer
107.	Flywheel Support Plate
108.	Belt - Drive
109.	Flywheel
110.	Fibre Washer
111.	Screw M2 x 5
112.	Spring Washer
113.	Flywheel Bearing Support
114.	Flywheel Bearing
115.	Pulley - Counter Drive
116.	Grub Screw for above
117.	Grub Screw (for Fan Pulley)
118.	Fan Pulley
119.	Motor
124.	E Ring 1.9
125.	Slip Clutch Assy.
126.	Spring - Slip Clutch
127.	Friction Lock Screw M2.6 x 4
128.	Motor Switch Holder
129.	Motor Switch
130.	Screw M3 x 12 ISO
131.	Friction Lock Screw M3 x 5 ISO
132.	Friction Lock Screw M3 x 5 ISO
133.	Friction Lock Screw M2.6 x 4
134.	Friction Lock Screw M2.6 x 4
135.	Latch Bar Support
136.	Screw M2.6 x 6
137.	Screw M2.6 x 4
138.	Record Switch Actuator Assembly
139.	Screw M2.6 x 5
140.	Play Lock Assy.
141.	Spring Washer
142.	Nut
143.	Washer
144.	Level Meter Lamp Switch
145.	Screw M2.6 x 4
146.	Direction Indicator Lamp Assembly
147.	Direction Indicator Lamp
148.	Direction Indicator Disc.
149.	End of Tape Stop Lever
150.	End of Tape Switch Assembly
151.	Direction Indicator Lamp Switch
152.	End of Tape Rotary Switch