

VORTEX CASSETTE DECK – OPERATION

MOTOR

Power to propel the tape is derived from a 110 volt 50Hz synchronous induction motor which is controlled by the Motor Switch (129). The Motor Switch is actuated by the Brake Release Plate (80) when the Fast Forward button, the Play button, or the Rewind button is pressed.