MAS1108
MAS1108A

SERVICE DATA

MISCELLANEOUS COMPONENTS

No. on Dial Parts Diagram	Description	Code No.
—	Arm, side (W/C switch)	CS.218.006
—	Assembly, cursor	CR.480.614
1	Assembly, dial drum	CR.382.804
—	Assembly, dial housing R.H. (Incl. Dial Assy.)	CR.272.604
—	Assembly, dial housing L.H. (Incl. Dial Assy.)	CR.272.605
—	Assembly, lamp cover R.H. (Incl. Dial Assy.)	CR.272.401
—	Assembly, lamp cover L.H. (Incl. Dial Assy.)	CR.272.400
—	Assembly, lamp holder	CZ.367.906
—	Assembly, pressure plate (Incl. Dial Assy.)	CR.391.207
6	Assembly, pulley spindle	CR.436.201
—	Assembly, slider hinge	CR.432.200
—	Assembly, T/C—on/off switch (complete)	CZ.200.218
—	Assembly, W/C switch (complete)	CZ.200.027
—	Assembly T/C clicker	CR.450.025
—	Assembly, W/C clicker	CR.450.026
—	Assembly, terminal	CZ.376.201
—	Badge, Mullard	CR.531.409
—	Bank, T/C switch	CZ.200.204
—	Bank, W/C switch	CZ.200.026
—	Brace, end (W/C switch)	CS.219.000
—	Bracket, cover attaching R.H. (Incl. Dial Assy.)	CS.229.803
—	Bracket, cover attaching L.H. (Incl. Dial Assy.)	CS.229.802
—	Bracket, tuning spindle	CS.224.603
—	Clamp, speaker mounting	CS.234.813
—	Clamp, incl. dial mounting to cabinet	CS.235.205
—	Cloth, baffle	CE.081.14

No. on Dial Parts Diagram	Description	Code No.
5	Cord, dial	CS.361.811
4	Cord, drum	CS.361.812
—	Cover, front (Incl. Dial Assy.)	CS.430.828
—	Cover, rear (Incl. Dial Assy.)	CS.430.827
—	Glass, dial, printed— MAS 1108	CS.412.255
	MAS 1108A	CS.412.291
—	Grommet, chassis mounting	CS.422.421
—	Grommet, power cord	CS.422.414
—	Key, W/C clicker	CS.365.803
—	Knob, tuning	CR.523.656
—	Mount, bakelite (Incl. Dial to Cabinet)	CS.235.813
—	Nut, tee (chassis mounting)	CH.603.214
—	Plate, clamping (Incl. Dial to Mount)	CS.235.200
—	Plate, friction (Incl. Dial Assy.)	CS.366.200
—	Plug, 2-pin polarised	CR.102.200
7	Pulley, wooden	CS.360.202
3	Ring, dial cord	CS.281.807
—	Rod, dial slide	CS.382.202
—	Socket, octal wafer	CZ.369.507
—	Socket, 2-pin polarised	CR.102.401
—	Socket, pick-up	CZ.370.106
8	Spindle, tuning	CS.351.410
—	Spring, compression (Incl. Dial Assy.)	CS.281.806
2	Spring, dial drum	CS.210.010
—	Spring, return (Incl. Dial Assy.)	CS.212.201
—	Spring, tuning spindle	CS.212.001
—	Spring, W/C clicker key	CS.211.802
—	Switch, mains on/off	CZ.220.001
—	Washer, friction (Incl. Dial Assy.)	CS.366.201
—	Washer, felt (knobs)	CS.424.018



DIAL CORD LAYOUT