91.	Speaker - 5″ permag. type 5C	K196	
	6″ permag. type 6H	K138	
	6″ permag. type 6L	K176	
	6x9 oval permag. type 6x9L	K158	
92.	6-pin oblong plug	A102/366	
93.	6-pin oblong socket	A101/366	
94.	15 amp fuse	PM219	SS only
95.	30 amp fuse	M385	SR only
96.	Foot switch (interim type) complete less lead	M391	
	Switch - less base plate and mount screws	M390	
	Base plate	309/81	
	Connecting lead 3 ft.	PA506	
	Connecting lead 4 ft.	PA507	
	Screw (2) ⅜″ x ⅛″ Csk. hd.	11/560-6	
	Washer (2) ⅛″ int. S/P.	1/562-4	
	Nut (2) ⅛″ Whit.	3/478-2	
	Foot switch (final type) complete with rubber cover cap (1/391) less lead and mount screw	M395	
	Mount screw 1½″ x No. 10 Bdr. hd. self-tapping	35/560-32	
	Connecting lead 3 ft.	PA512	
	Connecting lead 4 ft.	PA513	
97.	Solenoid 6-volt (part of tuning unit)	L122	SR only
98.	Solenoid 12-volt (part of tuning unit)	L123	SS only
99.	Selectomatic tuning unit 6-volt	L133	SR only
100.	Selectomatic tuning unit 12-volt	L134	SS only
101.	Antenna coil - less iron core	L135	
	Antenna coil iron core (blue spot)	11/766-2	
	Antenna coil iron core (brown spot)	11/766-3	
	Antenna coil iron core (white spot)	11/766-1	
102.	RF. coil - less iron core	L135	
	RF. coil iron core (blue spot)	11/766-2	
	RF. coil iron core (brown spot)	11/766-3	
	RF. coil iron core (white spot)	11/766-1	
103.	Osc. coil - less iron core	L136	
	Osc. coil iron core (blue spot)	11/766-2	
	Osc. coil iron core (brown spot)	11/766-3	
	Osc. coil iron core (white spot)	11/766-1	
	Knob - antenna matching control on side of receiver case	269/81	
	Vibrator Socket - 6-pin	PM146	
	Valve Socket - 7-pin	A104/58	
	Valve Socket - 9-pin	279/250	
	Valve Shield 6AN7	64/635	
	Vibrator Earth Clip	42/98	
	Clip for mounting IF. trans.	7/670	
	Speaker Socket - 2-pin	364/250	
	Speaker Plug – 2-pin – refer page 14	336/30C	
	Press Stud – earth lead – speaker – refer page 14	267/250	
	Fuse Holder - long section	11/245	
	Fuse Holder - short bayonet section	14/245	
	Fuse Insulator - cardboard tubing	15/245	
	Eyelet and Washer Assy. (2) moulded bakelite – fuse holder	17/245	
	Spring - fuse holder	89/30C-2	
	.5 MF 200V. DCW metal-clad generator armature terminal by-pass condenser	PC545	
	.5 MF 200V. DCW metal-clad ignition coil battery terminal by-pass condenser	PC545-1	
	Suppressor - 12,500 Ohm screw-in type	PR314	
	A+ Cable 19/.012″ T/C wire	WM15	
	Rear Mount Nut for rear mount stud 5/16″ Whit.	3/478-14	