



NOTES:- ARROWS ON POTENTIOMETERS INDICATE DIRECTION OF CLOCKWISE ROTATION.
 VOLTAGES IN BRACKETS ARE FOR NEGATIVE EARTH OPERATION.
 ALL VOLTAGES ARE MEASURED WITH NO SIGNAL INPUT BY A 20,000 OHM/VOLT METER.
 SOCKETS ARE SHOWN FROM PIN VIEW, PLUGS FROM WIRING VIEW.

AWA CAR RADIO MODEL 939 SERIES

