

AUTO RADIO SERVICE BULLETIN.

SUBJECT - INSTALLATION OF AERIAL AND SPEAKER LEADS TO  
1939 GENERAL MOTORS' CARS.

Some difficulty may be experienced in drawing the leads up the corner post. To obviate this, take a fish wire up the channel, which has its upper outlet immediately behind the reinforcing corner plate. To gain access to this outlet it will be necessary to lift the head lining above door and remove sheet steel strip which clamps head lining in position.

It will be found that the leads can be drawn up with ease, and in the case of the aerial, this lead can be dropped down without the use of a fish wire at all.

NOTE: Aerial lead goes down right hand side and speaker down left side.

OPERATION

Remove the head lining above door.

Remove steel strip which holds head lining in place.

Insert fish wire in channel which has its outlet behind this strip.

Remove screws in windshield garnish rail to prevent fouling of lead.

In the case of overcar antennae, the lead-in may be dropped down this channel, where its passage is quite free.