



CAR RADIO INSTALLATION INSTRUCTIONS

PAMPHLET 78742

Issue 1 (24-11-76)

Supplied by Amalgamated Wireless (Australasia) Ltd.

KIT No. : 81275/802

WHERE USED : FORD XC FALCON, ZH FAIRLANE

ITEM : MAGNETIC SHIELD FOR STEREO TAPE PLAYERS.

PURPOSE : To eliminate magnetic interference generated by heavy current carrying conductors in the wiring loom near the tape player.

INSTALLATION PROCEDURE:

1. Disconnect car battery earth lead.
2. Remove player escutcheon and its two supports.
3. From the instrument panel lower edge remove the centre of the three screws and the fuse box retainer rail (when fitted). Move fuse panel to its lowered position.
4. Remove rear support bracket.
5. Move player as far as possible to the rear. Remove screws securing front trimplate and remove same.
6. Remove player (disconnect power and speaker leads).
7. Refit trimplate, carefully mark point at right hand edge of trimplate in line with centres of the player mounting holes.
8. Remove trimplate and mark outline of shield on panel as shown. Without damaging the moulded faces cut or file to outline.
9. Fit shield to the player, refit unit and reconnect car battery.

