

21 STURT STREET, SOUTH MELBOURNE.

AUTO RADIO SERVICE BULLETIN.

SUBJECT - RECEIVER INSTALLATION.

MORRIS

AND MORRIS COWLEY.

MODELS 1924-1926 - Fit receiver to dash below petrol tank.

MODELS 1927-1928 - In narrow track models receiver must be mounted on special bracket, Part No. A1021.

MODELS 1929-1933 - Same as above except Morris Minor; Glove Box must be cut away in this model.

MODEL 1934. - Morris Cowley Six:  
Mount set on floor immediately in front of gear lever, making sure that gear lever is in its most forward position when clearing tone control knob.

Morris Isis: Normal mounting.

Morris London: Normal mounting.

NOTE: The early models have a magneto. 50,000 ohm Suppressor should be used.

From 1929 onwards, the automobiles use battery ignition when ordinary suppression methods will apply.

1934 Models. Trouble may be experienced by the action of the electric battery lift. A regular clicking noise is heard in speaker synchronising with each stroke of the petrol pump. Bypass the active lead of the pump to earth.