



CN600 (PIN VIEW)

<table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>7</td> <td>6</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>12</td> <td>11</td> <td>10</td> </tr> </table>						7	6	5	4	3	2	1	16	15	14	13	12	11	10
7	6	5	4	3	2	1													
16	15	14	13	12	11	10													
1	RL+	OUT	9	RR-	OUT														
2	RR+	OUT	10	GND	—														
3	RHEOSTAT(-)	IN	11	JLL +B	IN														
4	ACC +	IN	12	ANT.+B	OUT														
5	—	—	13	—	—														
6	FL+	OUT	14	TO BATTERY(+13.2V)	IN														
7	FR+	OUT	15	FL-	OUT														
8	RL-	OUT	16	FR-	OUT														

(CM30701F)