

LEKMEK 54B RECEIVER

VOLUME

TUNING

ON-OFF SWITCH

239
6v.

236
6v.

I-F-1

239
6v.

I-F-2

A

R.F

OSC

I-F-2


3 GANG
CONDENSER

236
6v.

INSTRUCTION
CHART

238
6v.

B-



6V ACCUM. - 80AH
 OR ANY 6V. AC
 OR ANY 6V. DC
 SUPPLY.

WARNING

DO NOT MAKE ANY ADJUSTMENT INSIDE CABINET WITHOUT FIRST DISCONNECTING "A" & "B" BATTERIES. NO "C" BATTERY IS REQUIRED VALVES ARE OF THE CATHODE TYPE WHICH ALLOWS THE FILAMENTS TO WORK OFF AC OR DC.

NOTE TRY SPEAKER LEADS TO SPEAKER BOTH WAYS AND LEAVE CONNECTED WHICH EVER WAY GIVES THE CLEARER REPRODUCTION

MANUFACTURED BY
LEKMEK RADIO LABORATORIES (N.S. GILMOUR)
SYDNEY