






BOTTOM VIEW OF PRINTED CIRCUIT BOARD





Variable Resistor for Tone



Socket


Variable Resistor for Off and Volume




Variable Air Condenser

Trimmer



Terminal for Earth and Ext. Ant.



Jack for Ext. Battery




Matching Transformer



SCHEMATIC DIAGRAM

SHARP BZ-780

S154



TUNING RANGE
 1: PHONO
 2: MW 535 - 1605 KC
 3: SW1 1.6 - 4.0 MC
 4: SW2 3.9 - 12 MC
 5: SW3 12 - 26 MC
 I.F. 455 KC

BATTERY
 (6 volts)