

TO CONVERT EL3794D/OOA TO /OOB

1. Remove (clear) lead from pin 4.
2. Remove (red) lead from pin 1, and connect to pin 4.
3. Connect (clear) lead to pin 1.
4. Mark blue spot on DIN plug.