





SWITCHES:
 S001 FM MODE SWITCH (ST-MONO)
 S002 BAND SELECTOR SWITCH (FM-AM)
 S003 PROGRAM SELECTOR SWITCH (PROG-TUNE)
 S004 MANUAL EJECT SWITCH
 S005 PULSE GENERATOR
 S006 MANUAL EJECT SWITCH

LAMPS:
 PL001 STEREO INDICATOR
 PL002 DIAL ILLUMINATION

NOTES:
 ALL RESISTORS ARE INDICATED IN OHMS (X 10)
 ALL CAPACITORS ARE IN P.F. (10³)
 THIS SCHEMATIC DIAGRAM IS SUBJECT TO CHANGE WITHOUT NOTICE

COMMUTATEURS:
 S001 COMMUTATEUR MODE DE FM (ST-MONO)
 S002 COMMUTATEUR SELECTEUR DE BANDE (FM-AM)
 S003 SELECTEUR DE PROGRAMME (PROG-TUNE)
 S004 COMMANDE MANUELLE (MANUAL EJECT)
 S005 GENERATEUR D'IMPULSIONS
 S006 COMMUTATEUR D'ÉJECTION MANUELLE

LAMPES:
 PL001 INDICATEUR STEREO
 PL002 ÉCLAIRAGE DU DIAL

REMARQUES:
 TOUS LES RÉSISTANCES SONT INDICUÉS EN OHMS (X 10)
 TOUS LES CONDENSATEURS SONT INDICUÉS EN P.F. (10³)
 CE SCHEMATA SCHEMATICO ÈSTA SUJETO CAMBIOS SIN AVISO PREVIO
 SANS RÉAVIS

INTERRUPTORES:
 S001 INTERRUPTOR DE MONO DE FM (ST-MONO)
 S002 INTERRUPTOR SELECTOR DE BANDA (FM-AM)
 S003 PROGRAMADOR DE PROGRAMA (PROG-TUNE)
 S004 INTERRUPTOR GENERAL
 S005 GENERADOR DE PULSOS
 S006 INTERRUPTOR EJECTOR MANUAL

LAMPARAS:
 PL001 INDICADOR DE ESTEREO
 PL002 ILUMINACION DEL DIAL

NOTAS:
 TODOS LOS RESISTORES ESTAN INDICADOS EN OHMS (X 10)
 TODOS LOS CAPACITORES ESTAN INDICADOS EN P.F. (10³)
 ESTE DIAGRAMA SCHEMÁTICO ESTÁ SUJETO CAMBIOS SIN AVISO PREVIO

CMKROPLANE:
 S001 FM MODUSKIPPLARE (ST-MONO)
 S002 BANDOMKAPPLARE (FM-AM)
 S003 PROGRAMVALJUE (PROG-TUNE)
 S004 STRÖMSTÄLLARE (MANUAL EJECTOR)
 S005 PULSGENERATOR
 S006 HÄNDRÄNSARE (EJECTOR)

LAMPOR:
 PL001 STEREOINDIKATOR
 PL002 DIAL-LAMPOR

ÖBS:
 ALLA RESISTORER INDIKERAS I OHM (X 10)
 ALLA KONDENSATORER INDIKERAS I P.F. (10³)
 DETTA SCHEMATA SCHEMATICO ÈSTA SUJETO CAMBIOS SIN AVISO PREVIO