



PERMEABILITY TUNER UNIT




OSC. SHUNT COIL 1st I.F. TRANS. 2nd I.F. TRANS. CONVERTER TRANS.




NUMBERS ASSIGNED TO TERMINALS OF COILS AND TRANSFORMERS ARE TO FACILITATE CIRCUIT TRACING OR COMPONENT REPLACEMENT AND MAY NOT BE FOUND ON THE UNIT.

TRANSISTOR 2N270
UNDERSIDE VIEW



POWER TRANSISTOR
UNDERSIDE VIEW



ALL VOLTAGES MEASURED BETWEEN POINTS INDICATED AND CHASSIS WITH A D.C. VACUUM TUBE VOLTMETER. NO INPUT SIGNAL.

IMPORTANT: REFER TO SERVICE BULLETIN JQX-1 FOR INSTRUCTIONS BEFORE ADJUSTING COLLECTOR CURRENT OF I138.

MODEL-JQX
NEGATIVE TO CHASSIS

I.F.-455 Kc/s.