Screw (2) $1\frac{1}{4}$" x 5/32"
Whit rd. hd. chassis
to cab. base - front 16/560-20

Screw (2) $\frac{5}{8}$" x 5/32"
Whit. rd.hd. chassis
to cab. base - rear 16/560-12
Washer (4) flat steel
1" x 3/16" chassis
mt. screws 6/214-5
Washer (4) shakeproof
5/32" int. chassis
mt. screws 1/562-5

Grub screw (2) 3/16" x 5/32"
Whit. pointed - ext. spindles 31/560-3

Rubber foot (4) base of
cabinet 96/47

Washer (6) flat, steel
9/16" x 11/64" cab. back
to cabinet. 67/30C

CABINET STYLING.

COLOUR	PART No.
WALNUT	295/221-1
BROWN MAHOGANY	295/221-2
LIGHT WALNUT	295/221-3
ROSE MAHOGANY	295/221-4
GOLDEN MAPLE	295/221-5
SYCAMORE	295/221-7

CONTROL KNOBS: (Used with Walnut, Brown Mahogany, Light Walnut and Rose Mahogany Cabinets.)

	COLOUR	PART NO.		COLOUR	PART NO.
Tuning	- GOLD	85/824	Tone, treble	-WALNUT	20/824-10
Volume	- GOLD	85/824-3	Tone. bass	- WALNUT	20/824-10
Gramo - Radio	- WALNUT	510/81-4	Wave, change	-WALNUT	510/81-6
ON/OFF Switch	- WALNUT	510/81-5			

CONTROL KNOBS: (Used with Golden Maple and Sycamore Cabinets)

	COLOUR	PART No.		COLOUR	PART NO.
Tuning	- GOLD	85/824	Tone, treble	-CREAM	20/824-11
Volume	- GOLD	85/824-3	Tone, bass	-CREAM	20/824-11
			Wave, change	-CREAM	510/81-16
ON/OFF Switch	- CREAM	510/81-15			
Gramo-Radio	- CREAM	510/81-14			