SHORT-WAVE BAND ALIGNMENT 14.4-18.3 Mc/s.

1.	To antenna terminal	15.2 Mc/s.	400 ohm non-inductive resistor	Turn wave change switch to 14.4-18.3 Mc/s. band position . Turn. cond. gang and dial pointer until centre of dial pointer is on 15.2 Mc/s. mark on dial. Leave the cond. gang and dial pointer set in this position and peak the 14.4-18.3 Mc/s. band oscl. coil ind. trim. (iron core) and the 14.4-18.3 Mc/s. band antenna and RF trans. ind. trimmers (iron cores) for max. output.
2.	To antenna terminal	18 Mc/s.	400 ohm non-inductive resistor	Turn cond. gang and dial pointer until centre of dial pointer is on 18 Mc/s. dial mark. Adjust 14.4-18.3 Mc/s. band oscl. coil trim. cond. for logging, then peak 14.4-18.3 Mc/s band antenna and RF trans. trim conds. for max. output.
3.	To antenna terminal	15.2 Mc/s.	400 ohm non-inductive resistor	Turn cond. gang and dial pointer until centre of dial pointer is on 15.2 Mc/s. dial mark. Leave the cond. gang and dial pointer set in this position and repeak the 14.4-18.3 Mc/s. band oscl. coil ind. trim (iron core) and the 14.4-18.3 Mc/s. band ant. and RF trans. ind. trimmers (iron cores) for max. output. Do not rock the cond. gang to and fro through the signal or move the dial pointer off 15.2 Mc/s. dial mark until after the ind. trimmer (iron core) of the three coils has been peaked for max.output.
4.	To antenna terminal	18 Mc/s.	400 ohm non-inductive resistor	Turn cond. gang and dial pointer until centre of dial pointer is on 18 Mc/s. mark on dial. Readjust 14.4-18.3 Mc/s. band oscl. trim. cond. for logging, then repeak 14.4-18.3 Mc/s. band antenna and RF trans. trim. conds. for max. output.