MAS1001 MAS1001A SERVICE DATA

MISCELLANEOUS COMPONENTS

No. on Dial Parts Diagram	Description	Code No.
—	Assembly, cabinet back	CR.572.023
—	Assembly, cursor	CR.480.633
—	Assembly, dial back plate	CR.022.203
1	Assembly, dial drum, MAS1001	CR.382.201
1	Assembly, dial drum, MAS1001A	CR.382.202
—	Assembly, lampholder	CZ.367.900
—	Assembly, speaker plate	CR.005.006
—	Badge Mullard	CR.531.409
—	Band, rubber (dial scale)	CS.433.407
—	Bracket, cabinet back mtg.	CS.244.603
—	Cabinet, walnut	CS.460.490
—	Cabinet, brown	CS.460.495
—	Cabinet, ivory	CS.460.500
—	Cabinet, green	CS.460.501
—	Cabinet, blue	CS.460.502
—	Cabinet, wine	CS.460.496
—	Clamp, dial	CS.228.561

No. on Dial Parts Diagram	Description	Code No.
—	Clip, coil can mounting	CS.235.831
—	Cloth, speaker baffle	CE.081.41
5	Cord, dial drive	CS.361.824
4	Cord, drum drive	CS.361.823
—	Knob, ivory	CS.432.617
—	Knob, ivory with line	CS.432.623
6	Pulley, wooden	CS.360.201
—	Ring, "C"	CS.281.802
3	Ring, dial cord	CS.281.807
—	Scale, dial, MAS1001	CS.412.306
—	Scale, dial MAS1001A	CS.412.302
—	Socket, noval wafer	CZ.369.702
—	Socket, octal moulded	CZ.369.515
7	Spindle, tuning	CS.351.315
2	Spring, dial drum	CS.210.020
—	Washer, felt (knobs)	CS.424.049



REAR VIEW
GANG CLOSED

DIAL CORD LAYOUT