Circuit No.	Miscellaneous	Part No.
100	Spark filter choke 6.8 micro H	4048-032-01
101a.	Push-Button permeability tuner unit, complete	4050-031-03
	consists of :	
	Iron sleeve (2) aer. and RF. coils	4065-021-01
	Iron sleeve osc. coil	4065-020-01
	Iron core (3)	4065-033-01
	Coil assy.	4036-036-01
PN-C2B	includes :	
only	Aerial coil	4036-034-01
	RF. coil	4036-034-01
	Osc. coil	4036-035-01
101b	Manual permeability tuner unit, complete	4050-034-02
	consists of :	
	Iron sleeve (2) aer. and RF. coils	4065-021-01
	Iron sleeve osc. coil	4065-020-01
	Iron core (3)	4065-033-01
	Coil assy.	4036-040-01
MN-C2B	includes:	
only	Aerial coil	4036-034-01
	RF. coil	4036-034-01
	Osc. coil	4036-035-01
102	No. 1 IF. transformer 455 Kc/s	4044-011-01
103	Oscillator shunt coil	4036-044-01
104	No. 2 IF. transformer 455 Kc/s	4044-011-02
105	No. 3 IF. transformer 455 Kc/s	4044-011-03
106	No. 4 IF. transformer 455 Kc/s	4044-011-04
107	Driver transformer - 10,000 to 30 ohms imped. (PN-C2B)	4042-024-02
107	Driver transformer - 10,000 to 30 ohms imped. (MN-C2B)	4042-024-01
108	Speaker choke - 15 ohms imped.	4048-026-02
109	Filter choke - laminated	4048-025-02
110		
111	RF. amp. transistor type 2N412	4128-011-02
112	Converter transistor type 2N412	4128-011-02
113	AGC. control diode type 1N295	4127-001-01
114	1st IF. amplifier transistor type 2N410 Green Spot	4128-010-03
115	2nd IF. amplifier transistor type 2N410 Red Spot	4128-010-04
116	3rd IF. amplifier transistor type 2N410	4128-010-02
117	Detector diode type 1N295	4127-001-01
118	Audio driver transistor type 2N591	4128-017-02
119	Audio Output transistor type 1138	4128-004-01
120		
121	Socket-collector current adjust	7222-033-01
122	Switch-part of circuit No. 85	
123	Speaker socket and lead assy.	4077-141-01
	Socket only	7222-039-01
124	Speaker plug	7171-025-01
125	Speaker 9" x 6" oval type 96L00/69/15 15 ohms imped.	4056-004-08
126		
127	Dial lamp 16 volt 3 watt	4068-003-02

Mechanical	
Socket - aerial lead-in	7222-037-01
Socket - power transistor	7222-036-01
Lead washer - power transistor	7102-027-01
Insulator (2) power transistor	7120-056-01
Screw (2) $^5/_8$" x No. 6 Phillips hd. - power transistor	7201-577-10
Socket - dial lamp	7222-029-01
Washer assy. - dial lamp socket	7261-030-01
Leatheroid washer - dial lamp socket	7261-109-01
Spring - dial lamp socket	7225-067-01
Clip - dial lamp socket	7055-021-01
Clip - speaker socket	7055-027-01
Heat Sink	7111-004-04
Terminal strip - 3 lug, type 2E	7231-201-01
Terminal strip - 5 lug, type 2E2 flat type	7231-502-01
Speednut (2) No. 4 driver transformer	7152-751-01
Screw (2) $^3/_8$" x No. 4 Phillips hd. - driver transformer	7201-576-11
Screw (14) $^1/_4$" x No. 6 Phillips hd. - covers to can	7201-577-12
Screw (8) $^1/_4$" x No. 4 Phillips head - printed circuit board to can	7204-576-15
Screw (2) Sems $^3/_8$" x $^1/_8$" Ch. hd. - perm. tuner to can	7198-931-11
Glass bead - transistor mount spacer	7120-026-01
Spacer nut (2) control bushes	7150-901-05
Washer (2) $^3/_8$" int. sh/proof	7262-024-02
Lead - battery brown 10"	1169-042-01
Terminal - battery lead	7244-003-01
Shroud - battery lead terminal	7291-003-01
Cover - feed thru capacitor	7065-025-01
Tuning and volume knob assy. (2)	7124-067-01
Spacer assy. tuning knob	7124-062-01
Tone Knob assy.	7124-068-01
Clip (2) spacer and tone knob	7186-010-01
Barrel nut (2) ext. thread	7150-853-02
Washer (2) chrome, escutcheon	7261-386-14
Barrel nut (2) int. thread	7150-854-03
Washer (2) chrome, panel	7261-484-02
Dial Lamp shield	7182-001-02
Knob - aerial tuning	7124-075-01

MN-C2B Only :

Escutcheon assy.	7084-039-01
includes :	
Diamond Dot	7081-001-01
Name strip "ALL TRANSISTOR"	7008-015-01
Dial reading - Aust. stations	7070-010-02
Screw (4) dial fastening	7209-107-03
Dial background assy.	7005-012-01
Dial pointer assy.	7113-007-01
includes :	
Pointer	7173-003-05
Spring - dial cord	7225-081-01
Dial cord - 30 ins.	1107-002-02
Dial reading - export calibration	7070-010-11