LOCATION OF PARTS



Fig. 1

① Cassette lid
② Eject button
③ Stop button
④ Play button
⑤ Fast forward button
⑥ Rewind button
⑦ Volume control
⑧ DC IN & Earphone jack
⑨ Battery compartment

STANDARD VALUE TO TEST

ITEM	VALUE	PARTS TO BE ADJUSTED	REMARKS
Pressure of Pressure roller.	430±70 gr-cm	Pressure roller lever spring.	——
Takeup tension.	65±15 gr-cm	——	——