PARTS LIST — MODELS T3-45 & T3-46 (continued)

REF.	PART NO.	DESCRIPTION
	SPARE PARTS (continued)	
	558-1531	Garrard Record Changer, Type 3000, fitted with Sonotone Type 9TA Cartridge and Type N9TADS Stylus
	211-0431	Cartridge, less styli
	611-0571	Styli
	517-2671	Knob
	517-2611	Knob, Push-Button, Red
	517-2621	Knob, Push-Button, Grey
	831-2501	Speaker, 8" Magnavox, Type 8WR
	441-0102	Speaker Gasket, 8"
	824-1161	Socket, Jack
	SPARE PARTS (continued)	
	668-0061	Plug, Jack
	575-0011	Microphone
	561-1791	Medallion, Microphone
	794-1891	Dial Scale
	381-0142	Dial Drum
	840-0252	Dial Cord Spring
	297-0011	Dial Cord, 53"
	671-0741	Pointer
	561-1432	Medallion, Trade Mark (T3-45)
	561-1571	Medallion, Trade Mark (T3-46)

This Parts List, with the following exceptions, is relevant to both Circuit Diagrams. Alterations to the Parts List for the original circuit (i.e., for chassis prior to Serial No. 1400), are as follows:

RESISTORS

DELETE:

R50a	740-0072	4.7K 10% ½W BTS
R52a	740-0072	4.7K 10% ½W BTS
R58a	740-0022	1K 10% ½W
R63a	740-0022	1K 10% ½W

ALTER:

R55 to	740-0142	100K 10% ½W
R56 to	740-0142	100K 10% ½W
R59 to	740-1732	330K 5% ½W
R60 to	740-1602	180K 5% ½W
R61 to	740-1602	180K 5% ½W
R62 to	740-1732	330K 5% ½W

CAPACITORS

DELETE:

C49a	284-0621	.01uF 20% 600V Di-Pol
C60	271-0741	.01uF +80% —20% 25V Redcap

ADD:

C19	280-0561	3300pF 20% 100V Styroseal

ALTER:

C44 to	269-1321	6.4uF 25VW Electro
C45 to	269-1321	6.4uF 25VW Electro
C47 to	280-3211	120pF 10% 100V Styroseal
C48 to	280-3211	120pF 10% 100V Styroseal
C51 to	269-1351	200uF 10VW Electro
C52 to	269-1351	200uF 10VW Electro
C54 to	283-1191	.039uF 10% 160V Polyester
C55 to	283-1191	.039uF 10% 160V Polyester