



# FERRIS



## MODEL 727 PORTABLE CAR RADIO



### DESIGN

The Ferris Model 727 Portable Car Radio is an efficient transistor portable, with preferred size, weight and battery. In addition it is a compact dash-mounted car radio giving excellent ignition noise free reception. This is achieved by the use of the Ferris SHIELDED CHASSIS technique and separate high gain aerial coil for connection to a car radio aerial. The Ferris Car Battery Adaptor M234BA (6 or 12v) permits connection to the car battery.

An under-dash 6 or 12v Gimbal Power Cradle, Type 234/727 P.C., is available which also provides connection to the car battery.

A protective diode in both the Car Battery Adaptor and the Gimbal Cradle prevents current flowing in the unit if connected in wrong polarity. Thus neither accessory nor set can be damaged. Adequate filtration ensures suppression of interference which could otherwise enter the set.

### SPECIFICATIONS

**BAND COVERAGE** - 525-1760 KHz  
**INTERMEDIATE FREQUENCY** - 455 KHz  
**SPEAKER** - 2 1/2" round, 15 ohm voice coil.  
**POWER OUTPUT** - undistorted 330 mW, max: 420 mW  
**CURRENT DRAIN** - 10 mA at 9V.  
**BATTERY** - Eveready Type ER2364.  
**TRANSISTORS** - 2N1639 Converter, 2N1638 1st IF Amplifier, 2N1638 2nd IF Amplifier, AC172 Audio Amplifier, AC125 Audio Driver, AC127 AC128 Power Output Complementary Pair.  
**DIODES** - OA90 Detector and AVC, OA90 Signal Overload.

### CONTROLS

**TUNING** by adjustable handspan wheel and vernier drive.

**VOLUME AND ON-OFF** are combined.

**AERIAL SWITCH** selects Ferrite rod aerial for portable use, or separate high gain aerial coil for correct matching to a standard top cowl or gutter grip aerial.

### EXTERNAL CONNECTIONS

**AERIAL SOCKET** for connection of a Ferris car radio or wire aerial.

**EXTENSION SPEAKER** for connection of an external speaker (15 ohm voice coil) or miniature magnetic earpiece. The set's own speaker is automatically silenced when either of the above items is connected.

**EXTERNAL BATTERY** for connection of Ferris 6 or 12v Car Battery Adaptor M234BA, Gimbal Cradle 234/727 P.C., or separate 9v dry battery - supplements the set's internal battery. This is beneficial where prolonged use of the set in the home is contemplated.

**DIAL SCALE AND HANDSPAN WHEEL.** The 727 is supplied with 6 dial scales, one for each state. To change the scale already fitted, it is preferable to use a tube spanner to remove the chrome hexagonal stud. Remove the "wheel" by exerting thumb pressure towards the small vernier knob and, at the same time, thrusting away from the dial scale (see FIGS. 3 & 4). The scale is easily removed and replaced.

When replacing the wheel, press its rim firmly against the rubber ring on the vernier tuning knob, then locate and fix it into the centre bush. Replace the hexagonal stud.

**VERNIER KNOB ADJUSTMENT.** Should the action of the small vernier knob be too tight or too loose adjustment can be made as follows:

1. Back off screw marked "A" by approx. 1/2 turn (see FIG. 4).
2. Slide the knob towards or away from the rim of the wheel as required.
3. Re-tighten screw.

### ROUTINE SERVICE ADJUSTMENTS

The condition of the battery can be quickly checked by switching the set on and connecting a voltmeter across the contacts as indicated in FIG. 1. If the voltmeter indicates 5v or less, then the battery should be replaced.

## ALIGNMENT PROCEDURE


For all alignment operations, connect the ground side of the signal generator to the metal shield and keep the generator output as low as possible to avoid AVC action. Set volume control at maximum.

NB. Use the correct alignment tool for making adjustments. Cores are easily broken by improper handling, thus making replacement of entire coil or transformer necessary. Set aerial switch to "C".

Note: When aligning the rod aerial as described, the output from the signal generator will need to be in the order of 0.3-1 mV, as it is only loosely coupled to the set via the capacity of the aerial switch.

Step	Connect sig. generator to	Tune sig. generator to	Tune receiver to	Adjust for max. output
1.	Base of 2N1639		Gang fully	IF3 Peak cores
2.	converter via	455 KHz	open	IF2 toward top
3.	0.1 $\mu$ F capacitor			IF1 of can
4.	Repeat above adjustments until no further increase can be obtained.			
5.	Aerial socket via standard	525 KHz	Gang fully closed	Osc. coil core L4
6.	dummy aerial	1760 KHz	Gang fully open	Osc. trimmer TR3
7.	Repeat steps 5 and 6 until band limits are 525-1760 KHz			
8.	Aerial socket via standard	600 KHz	600 KHz	Aerial coil core L2
9.	dummy aerial	1500 KHz	1500 KHz	Aerial trimmer TR2
Repeat steps 8 and 9 until no further increase can be obtained. Check sensitivity at 1500, 1000 and 600 KHz for satisfactory performance.				
Ferrite rod alignment: Set aerial switch to "P".				
1.	Aerial socket via dummy	1500 KHz	1500 KHz	Rod aerial trimmer TR1
2.	aerial. See note.	600 KHz	600 KHz	Slide winding L3 along ferrite rod
Repeat steps 1 and 2 until no further increase can be obtained.				

### FERRIS UNDER-DASH CRADLE TYPE 234/727 P.C. (6 OR 12 VOLT)



- CH1 TYPE 8214 for 12 volt cradle  
TYPE 8213 for 6 volt cradle
- D1 DIODE TYPE EZ10 or R205
- C1 .1 uf 25 volt CAPACITOR (used in 6 volt cradle only)

The receiver can be firmly clamped in this gimballed cradle which has car battery filter and polarity adjustment. A further refinement permits the set to be inclined at various angles for ease of tuning and directing of sound from its speaker.

To check that car battery current is reaching the set, proceed as follows:-

1. Refer to FIG. 1 and disconnect dry battery.
2. Plug in twin lead from cradle to connector marked EXT. BATTERY at end of set. The set should now operate from the car battery if connections to, and polarity setting of, unit are correct.
3. Refit set's own battery after test.

Do not operate set without speaker connected.




FIG. 1




FIG. 2




FIG. 3




FIG. 4

**BATTERY REPLACEMENT**

Remove back by releasing the single holding screw. After fitting a new battery, ensure an even fit of the moulded back before tightening the holding screw.



To gain access to receiver components, remove moulded back as previously described. Refer to FIG. 1 - remove screws marked "B" then, with the aid of a screwdriver, engage the slot "C" and lever off the rear metal lid. Note that the complete circuit alignment can be carried out when these lids have been removed.

**REMOVING "SHIELDED CHASSIS" FROM CASE**


1. Remove handspan wheel.
2. Remove volume control knob (knob pulls off).
3. Remove case back and rear metal lid.
4. Remove 3 screws marked "D" in FIG. 2.
5. Shielded chassis can now be swung clear of moulded case.
6. Lever off front metal lid. Both sides of the printed circuit board are now accessible, thus permitting replacement of any major component.

**DC RESISTANCE OF WINDINGS**


	in ohms
Aerial filter choke (L1)	5
Aerial coil primary	25
Aerial coil secondary	7
Ferrite rod aerial (L3)	1
Oscillator coil primary	0.25
Oscillator coil secondary total	2
IF1 primary	2
IF1 secondary	0.3
IF2 primary total	2
IF2 secondary	0.3
IF3 primary total	2
IF3 secondary	1



**COMPONENT LAYOUT M 727**  
 VIEWED FROM PRINTED WIRING SIDE OF BOARD.



# MODEL 727 - 7 TRANSISTOR PORTABLE CAR RADIO



## COMPONENT LIST

### Resistors (all 1/2 watt)

R1	15k	10%
R2	3.3k	10%
R3	1.5k	10%
R4	150Ω	10%
R5	560Ω	10%
R6	120k	10%
R7	820Ω	10%
R8	1k	10%
R9	27k	10%
R10	1.5k	10%
R11	1k	10%
R12	10k	10%
R13	330Ω	10%
R14	3.3k	10%
R15	1k	10%
R16	10k	Pot.
R17	22k	10%
R18	22k	10%
R19	1k	10%
R20	4.7Ω	10%
R21	330Ω	10%
R22	1k	10%
R23	68Ω	10%
R24	180Ω	NTC
R25	56Ω	10%
R26	680Ω	10%
R27	3.3Ω	10%
R28	3.3Ω	10%

### Capacitors

C1	0.1 μF	25V
C3	100 pF	125V*
C4	7.5 pF	500V
C5	0.047 μF	25V
C6	0.01 μF	25V
C7	0.047 μF	25V
C8	820 pF	125V*
C9	380 pF	125V*
C10	3.3 pF	500V
C11	0.047 μF	25V
C12	820 pF	125V*
C13	0.047 μF	25V
C14	0.047 μF	25V
C15	0.047 μF	25V
C16	0.047 μF	25V
C17	820 pF	125V*
C18	0.047 μF	25V
C19	0.047 μF	25V
C20	0.047 μF	25V
C21	0.047 μF	25V
* STYROSEAL		
Electrolytic		
EC1	25 μF	6V
EC2	100 μF	6V
EC3	3.2 μF	6V
EC4	3.2 μF	6V
EC5	300 μF	6V
EC6	100 μF	10V
EC7	100 μF	4V
EC8	820 μF	6V

### Transistors and Diodes

Q1	2N1639, 2N374, AF116
Q2	2N1638, 2N373, AF117
Q3	2N1638, 2N373, AF117
Q4	AC127, 2N649
Q5	AC125, 2N408
Q6	AC127, 2N649
Q7	AC128, 2N408
D1	OA90, 1N60A
D2	OA90, 1N60A

### Chokes and Coils

L1	Aerial choke Type 8326
L2	Aerial coil Type 7120
L3	Rod aerial coil Type 7122
L4	Osc. coil Type 7325

### IF Transformers

IF1	455 KHz	Type 9133
IF2	455 KHz	Type 9134
IF3	455 KHz	Type 9134

### Trimmers

TR1, TR2, TR3 — trimmers mounted on gang

### Switches

S1A, S1B, S1C — three-pole, two-position slide switch  
 S2 — single-pole, single-throw switch on volume control  
 Battery 9V Type 2364  
 Band coverage 525-1760 KHz  
 IF frequency 455 KHz

Total battery current 10 mA for 9V battery.

Collector current of output stage for zero signal, 2 mA.  
 All resistors 1/2W unless otherwise stated.

Note: All voltages checked with 40,000 ohms per volt meter at zero signal input.