


TECHNICAL INFORMATION AND SERVICE DATA




B17 RADIOLA EIGHT-TRANSISTOR MANTEL MODEL




B17

B18 RADIOLA EIGHT-TRANSISTOR PORTABLE MODEL



B18

B29 RADIOLA EIGHT-TRANSISTOR PORTABLE MODEL



B29

ISSUED BY
AMALGAMATED WIRELESS (AUSTRALASIA) LTD.

GENERAL DESCRIPTION

Model B17 is an eight-transistor, battery-operated, superheterodyne portable receiver designed for the Medium Wave Band. A socket is provided for connection of a car radio aerial or an external aerial.

Model B18 uses the same chassis assembly as B17 mounted in a moulded mantel cabinet. External aerial connections in this model are by means of the rear cabinet retaining screws.

Model B29 is an eight-transistor, battery-operated superheterodyne portable receiver. In relation to the B17 it incorporates new style cabinet construction, new dial scale and provision for Battery Saver connection.

ELECTRICAL AND MECHANICAL SPECIFICATIONS

Frequency Range 525-1,650 Kc/s
(570-182 metres)

Intermediate Frequency 455 Kc/s

Battery Complement 9 volt battery type 2364

Battery Consumption:

For zero audio output 14 mA

For 50 mW audio output 50 mA

For full audio output 110 mA

Loudspeaker:

Permanent Magnet No. 50090.

V.C. Impedance 80 ohms centre tapped at 400 c.p.s.

Undistorted Power Output 400 mW

Controls:

Tuning Control—front left-hand.

On/Off Volume Control—right-hand side.

Transistor Complement:

AWV 2N1636 or 2N1639 Converter

AWV 2N406 Overload

AWV 2N1634 or 2N1638 1st I.F. Amplifier

AWV 2N1634 or 2N1638 2nd I.F. Amplifier

AWV 2N406 1st Audio

AWV 2N408 Driver

AWV 2N217S Output

AWV 2N217S Output

A diode (OA90, OA80 or 1N295) is also used as Audio Detector and A.G.C.

Dimensions:

	B17	B18	B29
Height	5½"	4¾"	5¾"
Width	9¾"	9¼"	9¾"
Depth	3½"	3¼"	2¾"
Weight (with battery)	4 lbs.	3 lbs. 9 ozs.	4 lbs.

Component Removal and Replacement:

Always use a soldering iron which is very clean and just hot enough to achieve a quick soldering operation as prolonged application of heat will damage the printed wiring.

Before installing a replacement component, it is advisable to clear the contact hole by heating the contact area and pushing a tapered stainless steel wire into the hole. Small screwdriver kits are available on the market containing a suitable spiked bit.

To remove an I.F. transformer or oscillator coil it is desirable to have a suitable tip on the soldering iron as shown in Fig. 1. All seven connections on the transformer may be freed simultaneously and the transformer pulled from the board. This is the only satisfactory method: any other method using smaller irons will generally result in damage to either the board or the transformer or to both.

Transistors may be removed in a similar manner to the I.F. transformers using the $\frac{3}{8}$ " bit on the ORYX iron.

The coupling transformer may be removed by first disconnecting the five leads and then moving each mounting lug by approximately $\frac{3}{32}$ " at a time until both lugs are free.




Fig. 1—Soldering Bit and I.F. Removal

CHASSIS REMOVAL

Remove the volume control knob which is a push-on fit.

Remove the tuning knob locking screw and remove the tuning knob.

On the portable model lift up the back flap and remove the battery. On the mantel model remove the cabinet back secured by two screws and remove the battery.

Remove the four 6BA nuts, lock washers and plain washers holding the chassis to the front escutcheon.

With firm pressure from the front against the gang spindle, free the pointer disc and lift the chassis and board assembly out of the cabinet.

Remove the five screws and lock washers securing the board, lift the ferrite rod out of its supports and the board may be raised and turned through 90° to give access to both sides for servicing.

Installation for both models is the reverse of the above procedure, making sure of the following points:

When replacing the board make sure that the battery stop bracket is in position under the bottom board mounting screw.

When replacing the pointer disc, turn the gang fully clockwise and screw the disc on with a clockwise rotation. When fully on, align the indicating line across the arrow heads on the dial scale.

Replace the tuning knob and secure it with the locking screw without disturbing the pointer setting.

Switch the receiver on and tune to some known stations. The pointer should fall across the centre of the station markings. If it does not, remove the tuning knob, readjust the pointer to accommodate the error and reassemble the knob.

MECHANICAL REPLACEMENT PARTS

Item	Part No.	Item	Part No.
Chassis Assembly:		This includes the following items:	
Bracket, Battery Guide	63593	Badge, A.W.A.	61463
Circlip, Gang Spindle	4551	Dial Scale	60930
Chassis Mounting:		Fret, Moulded	60923
Nut, 6BA	493560	Plate, Front Die Cast	61496
Washer, 6BA I.T.L.	921206	Escutcheon Assembly, B29 (gold)	63590
Washer, 6BA Plain	15722	B29 (silver)	63591
Gang Mounting:		These include the following items:	
Grommet (3 off)	389262	Badge, A.W.A. (gold)	61463
Lug, Earthing	439085	(chrome)	61463/2
Screw, 4BA x $\frac{5}{16}$ ", Ch/Hd. (3 off)	714010	Dial Scale	37972
Spacer (3 off)	39624	Fret, Moulded	60923
Washer, Plain (2 off)	13156	Plate, Front Die Cast (gold)	63588
Support, L.H., Ferrite Rod	60933	(chrome)	63589
Support, R.H., Ferrite Rod	60934	Knob Assembly, Pointer	60928
Cabinet Fitting:		Knob Assembly, Tuning (gold)	63585
Case Assembly, B17	60218	(silver)	60922
B18 (Series)	60217	Knob Assembly, Off/Volume, B17	61460
B29	60242	B18	60925
Case, Carrying, B18 (Series)	61450	B29 (gold) ..	63597
Door, Battery, B18 (Series)	60932	B29 (silver) .	63596
Escutcheon Assembly, B17, B18	60916	Screw, Tuning Knob Retaining (gold)	60931
		(chrome) ..	60931/1
		Strap, Carrying, B17	61459

NOTE: When ordering, always quote the above Part Numbers. In the case of coloured parts, such as knobs, also quote the colour.

ALIGNMENT PROCEDURE

Manufacturer's Setting of Adjustments:

The receiver is tested by the manufacturer with precision instruments and all adjusting screws are sealed. Re-alignments should be necessary only when components in tuned circuits are repaired or replaced or when it is found that the seals over the adjusting screws have been broken. It is especially important that the adjustments should not be altered unless in association with the correct testing instruments listed below.

Under no circumstances should the plates of the ganged tuning capacitor be bent, as the unit is accurately aligned during manufacture and can only be re-adjusted by skilled operators using special equipment.

For all alignment operations, keep the generator output as low as possible to avoid a.g.c. action and set the volume control in the maximum clockwise position.

Testing Instruments:

- (1) Signal Generator, or
- (2) Modulated Oscillator.

If the modulated oscillator is used, connect a .22 megohms non-inductive resistor across the output terminals.

(3) No output transformer is used in this receiver since the speaker has a centre tapped 80 ohm voice coil and is connected directly to the collectors on the output transistors. For output measurement, if an indication only is required, Output Meter type 2M8832, switched to 5000 ohms and connected across the output collectors, should be adequate. For correct reading of power output an A.C. meter, with neither probe earthed, connected across the output collectors will measure the voltage across the 80 ohms load. The normal alignment level of 50mW occurs when 1.4 volts is indicated on the A.C. voltmeter.

- (4) I.F. Alignment Tool—Part No. 39462.

ALIGNMENT TABLE

ORDER	CONNECT "HIGH" SIDE OF GENERATOR TO:	TUNE GENERATOR TO:	TUNE RECEIVER TO:	ADJUST FOR MAX. PEAK OUTPUT
1	Aerial section of Gang	455 Kc/s	Gang fully closed	Cores in TR5, TR4 and TR3
Repeat adjustment until maximum output is obtained				
2	Inductively coupled to Rod Aerial*	600 Kc/s	600 Kc/s	L.F. Osc. Core Adj. (TR2)†
3	Inductively coupled to Rod Aerial*	1,650 Kc/s	Gang fully open	H.F. Osc. Adj. (C4)
4	Inductively coupled to Rod Aerial*	1,500 Kc/s	1,500 Kc/s	H.F. Aerial Adj. (C3)
Repeat steps 2, 3 and 4.				

* A coil comprising three turns of 16 gauge D.C.C. wire and about 12 inches in diameter should be connected between the output terminals of the test instrument, placed concentric with the rod aerial and distant not less than one foot from it.


† Rock the tuning control back and forth through the signal.

D.C. RESISTANCE OF WINDINGS

Winding	D.C. Resistance	Winding	D.C. Resistance
Aerial Choke L1	1	1st, 2nd and 3rd I.F. Transformers:	
Ferrite Rod Assembly TR1:		Primary	1.5
Primary 1-2	1.5	Secondary	*
Secondary 6-7	*		
Tertiary 4-5	*	Coupling Transformer:	
Oscillator Transformer TR2:		Primary	540
Primary 3-5	1.2	Secondary	540
Secondary 1-4	*		

* Less than 1 ohm.


The above readings were taken on a standard chassis, but substitution of materials during manufacture may cause variations and it should not be assumed that a component is faulty if a slightly different reading is obtained.



Circuit Variations

Jack SK1 fitted on model B29 only.

In later production, C5 and C29 will be replaced by $.0039\mu\text{f} \pm 80\%$ —20% Hi-K disc 225859.



CIRCUIT CODE—RADIOLA PORTABLES B17 AND B29—MANTEL B18

CODE No.	DESCRIPTION	PART No.
RESISTORS		
All Resistors $\pm 10\%$ carbon unless otherwise stated.		
R1	10K ohms $\frac{1}{2}$ watt	612025
R2	56K ohms $\frac{1}{2}$ watt	615161
R3	1.8K ohms $\frac{1}{2}$ watt	609077
R4	470 ohms $\frac{1}{2}$ watt	606588
R5	68K ohms $\frac{1}{2}$ watt	615494
R6	3.9K ohms $\frac{1}{2}$ watt	610556
R7	680 ohms $\frac{1}{2}$ watt	607281
R8	100 ohms $\frac{1}{2}$ watt	604031
R9	3.9K ohms $\frac{1}{2}$ watt	610556
R10	10K ohms $\frac{1}{2}$ watt	612025
R11	56K ohms $\frac{1}{2}$ watt	615161
R12	1K ohm $\frac{1}{2}$ watt	608025
R13	820 ohms $\frac{1}{2}$ watt	607665
R14	100 ohms $\frac{1}{2}$ watt	604031
R15	100 ohms $\frac{1}{2}$ watt	604031
R16	6.8K ohms $\frac{1}{2}$ watt	611526
R17	33K ohms $\frac{1}{2}$ watt	614460
R18	5.6K ohms $\frac{1}{2}$ watt	611293
R19	22K ohms $\frac{1}{2}$ watt	613653
R20	22 ohms $\frac{1}{2}$ watt	602320
R21	1.8K ohms $\frac{1}{2}$ watt	609077
R22	2.7K ohms $\frac{1}{2}$ watt	609862
R23	22K ohms $\frac{1}{2}$ watt	613653
R24	120 ohms $\frac{1}{2}$ watt	601077
R25	1K ohm $\frac{1}{2}$ watt	608025
R26	4.7K ohms $\frac{1}{2}$ watt	610932
R27	100 ohms $\frac{1}{2}$ watt	604031
R28	5.6 ohms $\frac{1}{2}$ watt	600724
R29	5.6 ohms $\frac{1}{2}$ watt	600724
R30	39K ohms $\frac{1}{2}$ watt	614684
R31	100 ohms $\frac{1}{2}$ watt	604031
RV1	2.5K ohms log carbon, Volume W/S	620032
CAPACITORS		
C1	10—200pf tuning Aerial	} 62270
C2	10—87pf tuning Osc.	
C3	3—12pf trimmer Aerial	
C4	3—12pf trimmer Osc.	
C5	0.0047 μ f $\pm 20\%$ Hi-K disc	225951
C6	0.01 μ f +80% —20% Hi-K	226372
C7	0.033 μ f +80% —20% 25VW disc	226741
C8	330pf $\pm 5\%$ N750 disc	223715
C9	25 μ f 3VW Electrolytic	229428
C10	0.1 μ f +80% —20% 25VW disc	227074
C11	2.2pf ± 5 pf NPO disc	221494
C12	330pf $\pm 5\%$ N750 disc	223715
C13	0.033 μ f +80% —20% 25VW disc	226741

CODE No.	DESCRIPTION	PART No.
C14	0.1 μ f +80% —20% 25VW disc	227074
C15	0.1 μ f +80% —20% 25VW disc	227074
C16	0.033 μ f +100% —0% K6000 rect.	226738
C17	2.2pf ± 5 pf NPO disc	221494
C18	330pf $\pm 5\%$ N750 disc	223715
C19	75 μ f 10VW Electrolytic	229676
C20	0.1 μ f +80% —20% 25VW disc	227074
C21	0.1 μ f +80% —20% 25VW disc	227074
C22	0.01 μ f $\pm 20\%$ 200VW Hunts W99	228609
C23	0.25 μ f $\pm 20\%$ 200VW Hunts W48	229007
C24	25 μ f 3VW Electrolytic	229428
C25	20 μ f 10VW Electrolytic	229307
C26	100 μ f 3VW Electrolytic	229706
C27	100 μ f 3VW Electrolytic	229706
C28	0.01 μ f +80% —20% Hi-K CDR 25VW	226372
C29	0.0047 μ f $\pm 20\%$ Hi-K 25VW disc	225951
C30	320 μ f 10VW Electrolytic	229776
C31	0.5 μ f $\pm 20\%$ 200VW Hunts W48	229116
C32	Not Used	
C33	4 μ f 4VW Electrolytic	228189
TRANSFORMERS		
TR1	Ferrite Rod	51242
TR2	Oscillator Coil	51636
TR3	1st I.F. Transformer	51272
TR4	2nd I.F. Transformer	51268
TR5	3rd I.F. Transformer	51270
TR6	Coupling Transformer	51145
L1	Aerial Choke (on TR1)	34336
TRANSISTORS AND DIODES		
VT1	AWV 2N1639 or 2N1636	
VT2	AWV 2N1638 or 2N1634	
VT3	AWV 2N406	
VT4	AWV 2N1638 or 2N1634	
VT5	AWV 2N406	
VT6	AWV 2N408	
VT7	AWV 2N217S	
VT8	AWV 2N217S	
MR1	Anodeon 1N295 or OA90 or OA80	
MISCELLANEOUS		
LS1	4" Speaker	50090
TH1	AWV AS2 or 130 ohms at 25° C. N.T.C. Thermistor	
SW1	ON-OFF Switch (on RV1)	
PL1	Battery Plug	34625
JK1	Jack, External Power Supply	63629
SK1	Aerial Socket	63584